


SELF-ADHESIVE PEEL & STICK INSTALLATION GUIDE

General

Our self-adhesive products allow for effortless, no mess installations. With a strong, long lasting, bond to the wall, that can be removed. Please follow the below installation guidelines to achieve the best results with your self-adhesive wallpaper.

Please note: Product not suitable for heavily textured paints



Advisory

- Freshly painted walls should be left for 4 weeks before application, Please refer to the paint manufacturers instructions for guidance.
- Ensure the wall is flat, clean, uniform light color and dry before application.
- Allow the wall paper to acclimatise in the room it will be applied in for a minimum of 24 hours before application.
- Always test compatibility prior to use.
- For damaged walls: Use a water based primer/sealant prior to installation.
- Repeat Step 4 after one week for longer lasting results.

Application Tools

- Plastic Smoother/Squeegee
- Razor knife/Sharp Utility Knife
- Spirit Level/Plumb Line
- Straight Edge/Ruler
- Pencil/Pen (to mark hang line)


Surface Preparation

- Ensure wall is clean, free from dust, or grease.
- If wiping with wet cloth, allow walls to dry before application.


Application Tools

1. Using a spirit level and pencil, mark a vertical line equal to a panels width on the wall, use this as a guide to hang the first panel as straight as possible.
2. Remove approx. 25 cm of backing paper and move the panel into the correct position.
3. Applying the adhesive to the wall (With plenty of pressure).
4. Remove trapped pockets of air from behind with squeegee.
5. Ensure the edges are firmly sealed flat to the wall.
6. Remove a further 25cm of backing paper and apply to the wall.
7. Repeat step 6 with each panel.


Step-By-Step GUIDE




1. Remove approx. 25cm of backing paper to expose the adhesive.




2. Line the edge of the paper up with the edge of the first panel.




3. Apply pressure to the join to fix it to the wall.




4. Moving from left to right apply pressure to the rest of the panel, fixing it to the wall.




5. Remove a further 25cm of backing paper.



6. Apply pressure left to right fixing the panel to the wall.



7. Repeat this process until the panel has been applied.



BORÅSTAPETER
MADE IN SWEDEN SINCE 1905